

LINKSYS®

A Division of Cisco Systems, Inc.

QUICK INSTALLATION

Wireless-G Broadband Router with 2 Phone Ports

Package Contents

- Wireless-G Broadband Router with 2 Phone Ports
- Setup CD-ROM with Norton Internet Security
- User Guide on CD-ROM
- Ethernet Network Cable
- Power Adapter
- Quick Installation


Model No: **WRP400**




CISCO™

1 Installation

- A.** Insert the Setup CD-ROM into your CD-ROM drive.



- B.** The *Welcome* screen appears on your monitor. Select the language you want to use. Then click the **Click Here to Start** button.



- C.** Follow the steps of the Setup Wizard.

1.



2.



3.



4.



5.



6.



7.



8.



9.



10.



- D.** When you are finished with the Setup Wizard and are waiting for your Internet connection, this screen appears. Continue with the steps of the Setup Wizard, and follow the on-screen instructions.



- E.** When you have finished setting up the Router, this screen appears. Click **Next**.



- G.** Click **Finish**.



NOTE: For more advanced settings and security options, refer to the User Guide on the CD-ROM.

For customer and technical support, contact your Internet Service Provider (ISP) or Internet Telephony Service Provider (ITSP). For additional information about the Router, refer to the User Guide on the CD-ROM.

Linksys Website
<http://www.linksys.com>

Linksys is a registered trademark or trademark of Cisco Systems, Inc. and/or its affiliates in the U.S. and certain other countries. Copyright © 2007 Cisco Systems, Inc. All rights reserved. Other brands and product names are trademarks or registered trademarks of their respective holders.

7072610NC-JL

LINKSYS®
A Division of Cisco Systems, Inc.